



ELEVATION

NOTES

Dial gauges shall be spring loaded in order to measure both extension and compression.

All dimensions are in millimeters (inches) unless otherwise shown.